



1 2 3 4 5 6 7 8



B - 02/01/07 - ...
 C - 17/12/07 - Length added.
 D - 02/09/08 - Item 6, 20, 32 and 34 removed. Item 35-37 added.
 E - 02/09/08 - Parts list corrected.

37	1	Bracket		5-00059	14	1	Piston	IDR-064	5-00071	
36	1	Bracket		5-00061	13	1	Bushing	IDR-05	5-00070	
35	1	Bracket		5-00060	12	1	Adapter	IDR-068	5-00074	
33	1	Nut			11	1	Spring	FJD-007	9-00033	
31	4	Screw			10	1	Outer sleeve	IDR-069	5-00064	
30	1	Screw			9	1	Front gable	IDR-067	5-00063	
29	1	Lock ring			8	1	Inner sleeve	IDR-0691	5-00065	
28	1	Lock ring			7	1	Front part	IDR-07	5-00066	
27	1	Locking ring	FJD-008		5	1	Piston rod	IDR-04	5-00069	
26	1	O-ring			4	1	Hammer	IDR-06	5-00068	
25	1	O-ring	IDR-11		3	2	Cheek	IDR-09	3-00200	
24	1	Piston guide			2	1	Rear gable	IDR-03	20-040	
23	1	Piston guide			1	1	Feeding block	IDR-0695	20-041	
22	1	Rod viper			Item Qty		Description		Standard	Material
21	1	Rod u-cup			DRAWN	APPR.	TOLERANCE	I drivare		WEIGHT
19	1	Front part nut	IDR-0693	5-00077	MFn		SS-ISO2768-1M			REPLACING
18	1	Muff	IDR-0692	5-00076	 IMHart AB KOPPARBERG SWEDEN		Spare Parts Dwg		REPLACED BY	
17	1	Feeding block nut	IDR-0694	5-00073					3-36400-001	
16	1	Front gable sleeve	IDR-066	5-00075	DWG NO		20-042	FORMAT	A3	DATE
15	1	Flange nut	IDR-065	5-00072	SCALE		1:2.5	SHEET		REV
										E